



## ENGLISH

### BEFORE 1st USE

#### Connecting your phone:











- Connect plugs in corresponding sockets in the base station. Plug the telephone line into telephone socket and insert power plug in an electrical outlet.
  - Insert batteries in Handset
  - After first time power up (base unit is connected to AC mains), welcome mode (country) will appear on the screen (Fig.1).
- Before you start to use your telephone, charge batteries continuously for 15 hours.
- ▲** Use only plug adapter and rechargeable batteries supplied with your phone.

#### Handset / Base Station Keys

- OK/Menu key**
- Back/ Intercom key**
- & 4. **Navigation key**
- Hang-up/Exit key**
- # key** - Press to insert **#**; In idle mode: Press and hold to access the call list.
- 0 key - During a call: Press and hold to insert a flash (R).
- \*key** - Press to insert **\***; In idle mode: press and hold to access the redial list.
- M1, M2** key - In idle mode/during a call: Press to dial pre-recorded number stored in direct mem.
- 📞 key\***
  - To block calls, it is necessary to subscribe to the Calling Number Presentation service, Contact your landline operator.
  - In standby mode: Direct access to the Call blocking menu
- Talk key / Loudspeaker**
- Paging key** - To locate handset / to start registration procedure.

\*Subject to subscription and availability of the service from the fixed line operator.

#### Display icons

-  Indicates that the Call Blocking function is activated. (See the attached Call Blocking addendum)
-  Indicates battery is fully charged.
-  Indicates battery is fully discharged.
-  Indicates that an external call is connected or held. Icon blinks when receiving an incoming call.
-  Indicates you have a new voice mail message\*.
-  Indicates you have new missed calls\*.
-  Displays when the alarm clock is activated.
-  Displays when handsfree is activated.
-  Displays when ringer volume is turned off.
-  Indicates that the handset is registered and within range of the base station. Icon blinks when the handset is out of range or is searching for a base.

#### Using the phone

##### Receive and end a call

- ( / )

##### Make a call

- ( ) either before or after dialing your number
- From redial list: Press and hold **\***/ **▲** or **▼**/ **( )**.
- From call log list\*: Press and hold **#**/ **▲** or **▼**/ **( )**.
- From direct memories: long press on **KEY 1** or **KEY 2** or **KEY 3** in idle mode.
- From phonebook: **▲** / **▲** or **▼** / **OK MENU**.
- During a call, to activate/desactivate handsfree: **( )**.

To make an internal call

- If only 2 registered handsets: **C/INT**.
- If more than 2 registered handsets: **C/INT** / **▲** or **▼** select the handset number / **OK MENU**.
- To ring all handsets to intercom: **C/INT** / **▲** or **▼** select **CALL ALL** / **OK MENU**.

To make a three-party conference call:

During call:

- Press **OK MENU** / select **INTERCOM** / **OK MENU** / **▲** or **▼** select handset number / **OK MENU**.
- Press **( )** on the called handset to answer.
- Long press **\*** on the calling handset to establish conference call.

#### Phonebook settings: 100 entries

##### To register in phonebook

**OK MENU** / **▲** or **▼** to select **PHONEBOOK** / **OK MENU** / **OK MENU** / select **ADD** / enter name of contact / **OK MENU** / enter number of contact / **OK MENU** / select melody / **OK MENU** / **OK MENU** to save as **VIP** or **C/INT** to save as **CONTACT**.

Notes:

- ! appears in the end of name of VIP entry.
- Phonebook is stored in base unit which is shared with duo, trio handsets.

##### To register the direct memories in keys M1,M2, 1, 2 & 3

**OK MENU** / **▲** or **▼** select **HS SETTINGS** / **OK MENU** / **▲** or **▼** select **DIRECT MEM** / **OK MENU** / **▲** or **▼** select **M1** or **M2**, **KEY 1** or **KEY 2** or **KEY 3** / **OK MENU** / edit or enter the number / **OK MENU**.

#### General settings

This phone can be customized according to your preferences, to access the different possibilities press: **OK MENU**.

- To customize handset (name, melody, language(Table 2),...): **▲** or **▼** select **HS SETTINGS** / **OK MENU**.

- To change PIN, registration handset, reset: **▲** or **▼** select **BS SETTINGS** / **OK MENU**.

This telephone is built-in with Smart Call Block feature\*. This feature will help you avoid nuisance calls by only allowing some numbers to make your phone ring. Default setting of Smart Call Block in this telephone is **OFF** but you can enable it via your phone settings, as explained in the following paragraphs.

\*This feature requires a subscription of Caller Line Identification service from your telephone service provider.

Setting	Explanations
<b>OFF</b>	Call Block function (Block all call with numbers) is Disabled. This is the default mode.
<b>ON</b>	Call Block function is set to Manual. Numbers registered in the black list will not go through and the phone will ring silently. Numbers can be added to the list while the phone is ringing and / or after a call (to enable, see part 1).
<b>CONTACTS</b>	In this automatic mode, any number not registered to your phonebook will be automatically be blocked and not cause your phone to ring. All calls from contacts registered to your phonebook will proceed normally. When this mode is chosen, <b>Contacts OK</b> is displayed on LCD in idle mode unless you have unread messages/missed calls (to enable, see part 2.1).

<b>VIPS</b>	In this second automatic mode, only calls from contacts registered as VIP in your phonebook will go through and cause your phone to ring. Any other number will not ring. When this mode is chosen, <b>VIPS OK</b> is displayed on the LCD in idle mode unless you have unread messages / missed calls (to enable, see part 2.2)
<b>ANONYME</b>	This extra feature allows you to block call that do not have a number attached to them (ie private calls, international calls, etc). This option can be enabled on top of any of the previous four (to enable, see part 3)

#### 1. Manual call block mode





Manual call block is the easiest option when starting out. When you chose **ON** in the call block settings, all calling numbers **registered in your blacklist** will be blocked. You can add/remove numbers from that list at any time.

##### How to block an incoming call:

When the phone is ringing and before answering, press **📞**. It will terminate the call and offer you the option to register the number to the blacklist in one click.

Then to confirm the registration of this number in the blacklist, press **< OK MENU >**- IMPORTANT: if you don't confirm, the number will not be added to the blacklist and the next call will go through normally.

##### 1.1. Enable MANUAL mode

<b>MENU</b>  	<b>CALL BLOCK</b>  	<b>BLOCK SET.</b>	<b>OFF</b>
			<b>ON</b>
			<b>VIP OK</b>
			<b>CONTACTS OK</b>

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Call Block**

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Block set**

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **ON** (manual mode) OR

In idle mode, press **📞** to access BLOCK SET. directly.

After you enable this option, the call block icon **📞** will be displayed on the LCD.

##### 1.2. Add numbers to Blacklist

In idle mode,

- Press **< 📞 >** key, **BLOCK SET.** is displayed, or Press **< OK MENU >** to press **<▲>** or **<▼>** to select **CALL BLOCK**, press **< OK MENU >** to show **BLOCK SET.**
- Press **< ▲>** or **< ▼>** to select **BLACKLIST.**
- Press **< OK MENU >**, press **<▲>** or **<▼>** to select **ADD**, enter number to be blocked, press **< OK MENU >** to save.

**NOTE:** 2 more ways to add incoming and outgoing call numbers in Block list:

- From incoming call numbers
  - Press **< OK MENU >**, press **<▲>** or **<▼>** to select **CALL LIST** or press and hold **< # >**.
  - Press **< OK MENU >**, press **<▲>** or **<▼>** to select call list entry.
  - Press **< OK MENU >**, press **<▲>** or **<▼>** to select to **ADD to BLIST.**
  - Press **< OK MENU >** to show selected number, press **< OK MENU >** to save to **Block list.**
- From outgoing call numbers
  - Press and hold **< \* >**, press **<▲>** or **<▼>** to select redial list entry.
  - Press **< OK MENU >**, press **<▲>** or **<▼>** to select to **ADD to BLIST.**
  - Press **< OK MENU >** to show selected number, press **< OK MENU >** to save to **Block list.**

##### 1.3. Edit numbers in Blacklist

In idle mode,

- Repeat step 1 and 2 in Section 1.2.
- Press **< OK MENU >**, press **<▲>** or **<▼>** to select **EDIT**, press **<▲>** or **<▼>** to select number to be edited, press **< OK MENU >** to edit, and then press **< OK MENU >** to save.

##### 1.4. Delete numbers in Blacklist

- 1.4.1. Delete a number from blacklist

In idle mode,

- Repeat step 1 and 2 in Section 1.2.
- Press **< OK MENU >**, press **<▲>** or **<▼>** to select **DELETE**, press **<▲>** or **<▼>** to select number to be deleted, press **< OK MENU >**.

- 1.4.2. Delete all numbers from blacklist





In idle mode,

- Repeat step 1 and 2 in Section 1.2.
- Press **< OK MENU >**, press **<▲>** or **<▼>** to select **DELETE ALL**, press **< OK MENU >**, **CONFIRM?** is shown, and then press **< OK MENU >** to confirm.

#### 2. Automatic call block mode

##### 2.1. VIPS only

In this restrictive automatic mode, only calls from numbers registered as VIP in your phonebook will go through and make your phone ring.

<b>MENU</b>  	<b>CALL BLOCK</b>  	<b>BLOCK SET.</b>	<b>OFF</b>
			<b>ON</b>
			<b>VIP OK*</b>
			<b>CONTACTS OK</b>





Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Call Block**

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Block set**

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **VIP OK** (Automatic mode)

##### 2.2. Contacts only

In this broad automatic mode, only calls from contacts registered in your phonebook (normal and VIP) will go through and make your phone ring.

<b>MENU</b>  	<b>CALL BLOCK</b>  	<b>BLOCK SET.</b>	<b>OFF</b>
			<b>ON</b>
			<b>VIP OK</b>
			<b>CONTACTS OK</b>

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Call Block**

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Block set**

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Contacts OK** (Automatic mode)

#### 3. Anonymous call block mode

This feature allows you to block numbers that do not display a number on your phone. It can be enabled or disabled independently from the previous call block modes.

<b>MENU</b>  	<b>CALL BLOCK</b>  	<b>BLOCK ANONYM</b>	<b>PRIVATE*</b>
			<b>ALL</b>
			<b>OFF</b>

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Call Block**

Press **< OK MENU >**, press **<▲>** or **<▼>** to select **Block anonym**

Press **< OK MENU >**, press **<▲>** or **<▼>** to select one of the options

##### 3.1. Block Private Calls

This mode will block incoming calls that have been purposely kept their numbers private from you.

In idle mode,

- Press **< 📞 >** key, BLOCK SET. is displayed, or Press **< OK MENU >** to press **<▲>** or **<▼>** to select **CALL BLOCK**, press **< OK MENU >** to show **BLOCK SET.**
- Press **<▲>** or **<▼>** to select **BLOCK ANONYM.**
- Press **< OK MENU >**, press **<▲>** or **<▼>** to select **PRIVATE**, press **< OK MENU >** to confirm.
- 📞** will be displayed on the lower side of LCD.

##### 3.2. Block All Anonymous Calls

This mode will block all incoming calls, including private calls, international calls, pay phone and other out-of-area calls.

In idle mode,

- Repeat step 1 and 2 in Section 3.1.
- Press **< OK MENU >**, press **<▲>** or **<▼>** to select **ALL**, press **< OK MENU >** to confirm.
- 📞** will be displayed on the lower side of LCD.

##### 3.3. Set Block Anonymous Calls OFF

In idle mode,

- Repeat step 1 and 2 in Section 3.1.
- Press **< OK MENU >**, press **<▲>** or **<▼>** to select **OFF**, press **< OK MENU >** to confirm.
- 📞** will only disappear from the LCD if the regular call block (see 1. And 2.) is also set to OFF.

#### TROUBLESHOOTING

As a general rule, if a problem occurs, remove the batteries from **all** handsets for about 1 minute, then disconnect and reconnect the power supply to the base and reinstall the handset batteries. For more information, you can download full user guide or get on-line assistance *www.alcatel-home.com*

#### SAFETY



This telephone is not designed for Emergency calls when the main power fails.


Do not use your telephone to notify a gas leak or other potential explosion hazard.

Do not open your device or its power supply to avoid risk of electrical shock. Do not attempt to open the batteries, as they contain hazardous chemical substances.

Your telephone must be located in a dry place away from hot, humid and direct sunlight condition. To avoid radio signal interference, place the phone at least 1 meter away from other electrical appliances or other phones.

#### ENVIRONMENT

  This symbol means that your inoperative electronic appliance must be collected separately and not mixed with the household waste.

 The European Union has implemented a specific collection and recycling system for which producers are responsible.

*Help us protect the environment in which we live!*

## CE

Hereby, ATLINKS EUROPE declares that the radio equipment type DECT is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: *www.alcatel-home.com*

Average power per channel: 10mW
Maximum Output Power (NTP): 24dBm
Frequency Range : 1880-1900MHz

Hereby, ATLINKS EUROPE declares that the radio equipment type DECT is in compliance with Legislation: Radio Equipment Regulations 2017 (SI 2017/1206). The full text of the declaration of conformity is available at the following internet address: *www.alcatel-home.com*

## UK CA

**ATLINKS Europe**  
28 Boulevard Belle Rive  
92500 RUEIL-MALMAISON - France  
RCS Nanterre 508 823 747

**ATLINKS UK Ltd**  
3rd Floor, Waverley House  
7-12 Noel Street, London, W1F 8GQ - UK  
Company registration: 13809295

*www.alcatel-home.com*

Alcatel is a trademark of Nokia, used under license by Atlinks.

F685 / F685 Duo\_RU  
A/W no.: 10002798 Rev.1 (RU/EN)  
Made in P.R.C.